

Enjoy your jacuzzi!

Thank you for your help in maintaining this unit.

- Close drain and fill jacuzzi until water level is at least two inches above jets.
- Press the button on the rim of the jacuzzi to turn the whirlpool system on and off.
- Please do not turn on the whirlpool system if the jets are not completely immersed, as this can damage the circulation pump.
- Please turn the whirlpool system off before exiting the jacuzzi.

JACUZZI INSTRUCTIONS



INSTRUCCIONES DE USO:

- Cierre el drenaje y llene el jacuzzi hasta que el nivel del agua esté al menos 4 cm por encima de los jets.
- Presione el botón de encendido y apagado en el borde del jacuzzi para activar el sistema de hidromasaje.
- Por favor, no encienda el sistema de hidromasaje si los jets no están completamente sumergidos, ya que esto puede dañar la bomba de circulación.
- Antes de salir, por favor apague el sistema de hidromasaje.

Gracias por su amable ayuda en el mantenimiento de esta unidad.

¡Disfrute de su jacuzzi!